



Pressure Vs Torque Conversion Chart - TITAN T TOOLS

PSI	Bar	T1		T3		T5		T8		T10		T25	
		Ft.Lb	Nm	Ft.Lb	Nm	Ft.Lb	Nm	Ft.Lb	Nm	Ft.Lb	Nm	Ft.Lb	Nm
1500	103	204	277	478	649	816	1107	1186	1609	1614	2190	3782	5132
1600	110	218	296	510	693	871	1182	1267	1719	1724	2340	4041	5483
1700	117	233	316	543	736	926	1256	1348	1830	1835	2490	4300	5834
1800	124	247	335	575	780	980	1330	1430	1940	1945	2639	4558	6185
1900	131	262	355	608	824	1035	1405	1511	2050	2056	2789	4817	6536
2000	138	276	374	640	868	1090	1479	1592	2160	2166	2939	5076	6887
2200	152	304	413	709	962	1204	1633	1758	2385	2388	3240	5593	7589
2400	165	333	452	778	1056	1317	1787	1924	2611	2609	3540	6110	8291
2600	179	361	490	848	1150	1431	1941	2090	2836	2831	3841	6628	8993
2800	193	390	529	917	1244	1544	2096	2256	3061	3052	4142	7145	9694
3000	207	418	567	986	1338	1658	2250	2422	3286	3274	4442	7662	10396
3200	221	446	606	1047	1420	1769	2400	2586	3508	3495	4742	8178	11096
3400	234	475	644	1108	1503	1880	2550	2749	3730	3716	5043	8693	11795
3600	248	503	683	1168	1585	1990	2701	2913	3952	3938	5343	9209	12495
3800	262	532	721	1229	1668	2101	2851	3076	4174	4159	5643	9724	13195
4000	276	560	760	1290	1750	2212	3001	3240	4396	4380	5943	10240	13894
4200	290	588	798	1355	1838	2323	3152	3409	4625	4600	6242	10757	14595
4400	303	617	837	1420	1926	2434	3302	3578	4854	4820	6540	11274	15297
4600	317	645	875	1484	2014	2544	3452	3746	5083	5040	6839	11790	15998
4800	331	674	914	1549	2102	2655	3603	3915	5312	5260	7137	12307	16699
5000	345	702	953	1614	2190	2766	3753	4084	5541	5480	7436	12824	17400
5200	359	730	991	1679	2278	2878	3906	4248	5764	5695	7728	13319	18072
5400	372	758	1028	1744	2366	2991	4058	4412	5986	5910	8020	13814	18743
5600	386	786	1066	1808	2454	3103	4211	4576	6209	6126	8312	14308	19414
5800	400	814	1104	1873	2542	3216	4363	4740	6431	6341	8604	14803	20086
6000	414	842	1142	1938	2630	3328	4516	4904	6654	6556	8896	15298	20757
6200	427	869	1179	2001	2715	3448	4679	5066	6873	6771	9188	15770	21398
6400	441	896	1216	2064	2801	3569	4842	5227	7093	6986	9480	16243	22039
6600	455	924	1253	2128	2887	3689	5006	5389	7312	7202	9772	16715	22680
6800	469	951	1290	2191	2973	3810	5169	5550	7531	7417	10064	17188	23321
7000	483	978	1327	2254	3058	3930	5332	5712	7750	7632	10355	17660	23962
7200	496	1004	1363	2313	3139	4032	5471	5869	7963	7863	10669	18156	24636
7400	510	1031	1399	2372	3219	4134	5609	6026	8176	8094	10983	18653	25309
7600	524	1057	1434	2432	3299	4236	5748	6182	8389	8326	11297	19149	25983
7800	538	1084	1470	2491	3380	4338	5886	6339	8601	8557	11610	19646	26656
8000	552	1110	1506	2550	3460	4440	6024	6496	8814	8788	11924	20142	27330
8200	565	1137	1542	2606	3536	4548	6172	6653	9027	9001	12213	20638	28003
8400	579	1164	1579	2662	3612	4657	6319	6810	9240	9214	12501	21135	28677
8600	593	1190	1615	2718	3688	4765	6466	6966	9452	9426	12790	21631	29350
8800	607	1217	1652	2774	3764	4874	6613	7123	9665	9639	13079	22128	30024
9000	621	1244	1688	2830	3840	4982	6760	7280	9878	9852	13368	22624	30697
9200	634	1272	1725	2888	3919	5089	6905	7438	10092	10072	13666	23120	31371
9400	648	1299	1763	2947	3998	5196	7051	7596	10307	10291	13964	23617	32045
9600	662	1327	1800	3005	4078	5304	7196	7754	10521	10511	14262	24113	32718
9800	676	1354	1838	3064	4157	5411	7342	7912	10735	10730	14560	24610	33392
10000	690	1382	1875	3122	4236	5518	7487	8070	10950	10950	14858	25106	34065

Pressure Vs Torque TITAN Conversion Chart are only for information and must not be used to set up a TITAN tool .Only calibration chart delivered with the tool must be used to make the set up .